



A R K T U R A

ARKTURA LLC  
18225 S. Figueroa  
Gardena, CA 90248

O. +1.310.532.1050  
F. +1.310.881.128  
www.arktura.com

## ARKTURA FURNITURE CLEANING INSTRUCTIONS

- As the case may be, only clean water, with slight additives of neutral washing agents (pH 5 – 8), is to be used with the aid of soft, non-abrasive cloths, rags or industrial cotton. Strong rubbing is not to be undertaken.
- The removal of greasy, oily or sooty substances can take place with the use of white spirit free of aromatic compounds or isopropyl alcohol (IPA). Residues of adhesives, silicone cartouche or adhesive tapes, etc., can also be removed in this way.
- Use no solvents, or similar, containing ester, ketones, alcohol, aromatics, ethylene glycol or halogenated hydrocarbon.
- Due to the danger of changes in a color tone, or effect, a test for suitability is to be undertaken for metallic coatings.
- Use no scratching, abrasive agents.
- Use no strong acids or alkaline detergents and introfiers.
- Use no detergents of unknown composition.
- Detergents must not be used at temperatures higher than a maximum of 25°C. Use no steam-jet devices.
- The maximum exposure period of these detergents must not exceed one hour: when necessary, the entire cleaning process can be repeated after at least 24 hours.
- Rinsing with clean cold water is to take place immediately after every cleaning process.